

**SUPERIDE STAINLESS
SPINDLE ASSEMBLY
INSTRUCTIONS**

Assemble the Caliper Bracket or Rotor Cover onto the Spindle with the caliper mounting ears pointing toward the steering arm on the spindle. Attach with the enclosed screws. Some form of thread locking compound should be used, such as Loctite Red Permanent thread locking compound or equivalent. Torque to 30-35 ft/lbs.

IN-087

**SUPERIDE STAINLESS
SPINDLE ASSEMBLY
INSTRUCTIONS**

Assemble the Caliper Bracket or Rotor Cover onto the Spindle with the caliper mounting ears pointing toward the steering arm on the spindle. Attach with the enclosed screws. Some form of thread locking compound should be used, such as Loctite Red Permanent thread locking compound or equivalent. Torque to 30-35 ft/lbs.

IN-087

**SUPERIDE STAINLESS
SPINDLE ASSEMBLY
INSTRUCTIONS**

Assemble the Caliper Bracket or Rotor Cover onto the Spindle with the caliper mounting ears pointing toward the steering arm on the spindle. Attach with the enclosed screws. Some form of thread locking compound should be used, such as Loctite Red Permanent thread locking compound or equivalent. Torque to 30-35 ft/lbs.

IN-087

**SUPERIDE STAINLESS
SPINDLE ASSEMBLY
INSTRUCTIONS**

Assemble the Caliper Bracket or Rotor Cover onto the Spindle with the caliper mounting ears pointing toward the steering arm on the spindle. Attach with the enclosed screws. Some form of thread locking compound should be used, such as Loctite Red Permanent thread locking compound or equivalent. Torque to 30-35 ft/lbs.

IN-087