



# **BT-661**

## **67-72 C10**

### **CHASSIS BRACE**

For questions on installations please call 800-841-8188 In Illinois (847) 487-0150



- 1.) Start by supporting the transmission and remove the factory transmission and trailing arm crossmembers.



For questions on installations please call 800-841-8188 In Illinois (847) 487-0150



- 2.) Position the C-shaped brackets in the truck frame. Bolt the chassis stiffener to the brackets. The rear of the chassis brace will install in the same position as the factory trailing arm. Mark the frame to drill the mounting holes.



For questions on installations please call 800-841-8188 In Illinois (847) 487-0150

